



PHRASEOLOGY (AUSTRALIAN FIRs)

Level Requirements:	Phrasing
By position with level instruction	DESCEND TO REACH (level) BY (POSITION)
By position	REQUIREMENT TO REACH (level) BY POSITION
By offset position with level instruction	DESCEND TO REACH (level) BY (distance) NORTH/SOUTH/EAST/WEST OF (position)
By offset position	REQUIREMENT TO REACH (level) BY (distance) NORTH/SOUTH/EAST/WEST OF (position)

Holding:	Phrasing
Instruction	HOLD AT (position)
Cancellation	CANCEL HOLD
Management	CONTINUE OUTBOUND TURN INBOUND NOW
Reports	REPORT TURNING OUTBOUND REPORT TURNING INBOUND

Time Requirements:	Phrasing
Instruction	ADJUST SPEED TO CROSS (position) AT TIME (time) [AT {speed}]
Speed at position	CROSS (position) AT (speed)

Other phrases:	Phrasing
QNH issuance	Q.N.H (four digits)
Level instructions	CLIMB/DESCEND TO (level) CLIMB/DESCEND TO AND MAINTAIN (level)
Vectoring	TURN LEFT/RIGHT HEADING (three digits) [reason]
Reasons	FOR SEPARATION DUE TRAFFIC DUE CROSSING/OPPOSITE DIRECTION/CONVERGING TRAFFIC
Direct Tracking	[RESUME OWN NAVIGATION] TRACK DIRECT TO (location)